



HP 15-d076nr Battery Replacement

Replace a dying or damaged battery on your HP 15-d076nr to restore power to the laptop.

Written By: Amy Weed



INTRODUCTION

This guide details how to replace the battery on an HP 15-d076nr. If your laptop does not stay on, shuts off, or won't charge, this may be the guide for you.



PARTS:

- [HP Battery Pack - 3 Cell Li-Ion, 2.8Ah, 31Wh](#) (1)

Battery

Part # 746641-001

Step 1 — Battery



- Orient the laptop upside down so that the back of the laptop, where the battery is located, faces you.
- Locate the left and right switches at the bottom of the laptop.

Step 2



- Move the right switch to the left so that the orange unlock symbol is showing.

Step 3



- Move the left switch to the right, covering the battery symbol, and hold.

Step 4



- While holding the left switch in place, slide the battery towards you and away from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-19 02:44:38 AM.